

RHS/RHS-P Relative Humidity Sensor

Monitor humidity in your building

The Relative Humidity Sensor comes in two models: the standard version (RHS) and the extended version (RHS-P).

RHS



The RHS is designed to monitor relative humidity at the control. The RHS comes with the mounting hardware to mount the sensor in the control enclosure.

The RHS-P is designed to monitor relative humidity in remote locations (away from the control). The RHS-P comes with the mounting hardware and cable to mount the sensor up to 100 feet (30.5 m) away from the control.

RHS-P



Features

- ◆ Easy installation
- ◆ 90-day limited warranty

Other requirements and information

- ◆ The RHS and RHS-P are designed only for the Local Environment Monitor, OMNI Weather Station, and Supra.
- ◆ For more information about the Relative Humidity Sensor or other Phason products, contact your dealer or visit www.phason.ca.

