

Supra version 2.00 release


May 20, 2008



New features

- ◆ **Startup timer:** The startup timer allows you to delay the startup of the Supra's loads when the control returns from a power failure. Configuring the timer allows you to distribute the initial startup load the backup generator must handle, allowing you to use a lower-capacity, more-economical generator.
- ◆ **Temperature setback:** Temperature setback allows you to automatically change the temperature set point for a specific period during the day.
- ◆ **Variable DC stages:** The Variable DC Expansion Kit (K210050) allows you to connect equipment that requires a 0 to 10 V input, such as variable frequency drives. The kit installs in seconds and has four outputs you can configure for cooling or heating. Each output has its own settings and functions the same as the Supra's other variable stages.

The expansion kit is available for Supras manufactured in June 2005 or later. Supra's manufactured since that time have a connector labeled CON6 in the upper-left corner of the circuit board. If your Supra has the connector, you can install the expansion kit.



- ◆ **Tunnel ventilation mode:** In tunnel ventilation mode, when the zone temperature is at or above the tunnel set point, stages and relays configured for tunnel mode react as follows.
 - ◆ Actuators – move to position zero (close the inlet)
 - ◆ Curtains – close the curtain
 - ◆ Cool relays and temperature-based duty cycles – switch off the relay
 - ◆ Variable stages – set the output to 0%
- ◆ **Improved status display:** The status display now includes relay run (on) durations and the current day's high and low temperatures.
- ◆ **Daily log:** The daily log lists the high and low zone and outside temperatures and humidity, total water usage, and total relay on durations. The Supra updates the log each hour and keeps a daily history. The daily log replaces the temperature log.

Upgrading your Supra

Upgrade your Supra to version 2.00 using an Intaglio updater device. For more information about the Intaglio, contact your dealer or visit www.phason.ca. To purchase or upgrade an existing Intaglio, contact your dealer or Phason.

Phason Inc.

2 Terracon Place

Winnipeg, Manitoba, Canada

R2J 4G7

Phone: 204-233-1400

Fax: 204-233-3252

E-mail: support@phason.ca

Web site: www.phason.ca