

## Technical service bulletin 17

April 25, 2006

### Subject

Determining the correct actuator feedback potentiometer wiring can be difficult. Service bulletin 17 explains how to determine the correct wiring.



### Issue

After installing a new actuator or potentiometer, or due to age-related potentiometer wear, the actuator might not move correctly.

Common symptoms include:

- ◆ The actuator oscillating back and forth
- ◆ The actuator not traveling the full stroke during calibration

### Resolution

The feedback potentiometer wiring must be properly connected to the control. Determining the correct wiring can be difficult on some actuators or potentiometers.

Potentiometers have three wires: positive (+), negative (-), and feedback (FB). If the feedback wire is not connected to the FB terminal on the control, the actuator will not function properly.

Because the wires are often different colors and are not always labeled the same as above, measuring the resistance between the wires is the best way to determine which wire is the feedback wire.

Follow the steps on the next page to measure the resistance and determine the correct wiring.



Before checking the potentiometer wires, verify that the power wires are properly connected.

If your control has manual mode, test the actuator using manual mode. If your control does not have manual mode and you are unsure how to verify the power wires, call Phason Customer Support.

1. Manually move the actuator away from the end of its stroke by at least a quarter of its total stroke.
2. Disconnect all three potentiometer wires from the control.
3. Number the wires 1, 2, and 3, in any order.
4. Set your ohmmeter to measure the potentiometer's maximum resistance, normally 20,000  $\Omega$ .
5. Measure and record the resistance between wires 1 and 2. \_\_\_\_\_  $\Omega$
6. Measure and record the resistance between wires 1 and 3. \_\_\_\_\_  $\Omega$
7. Measure and record the resistance between wires 2 and 3. \_\_\_\_\_  $\Omega$
8. The pair of wires with the highest measured value are the positive and negative wires. Connect the wires to the positive and negative actuator terminals on the control. At this time, do not be concerned with which wire you connect to which terminal.
9. Connect the remaining wire to the feedback terminal.
10. Test the actuator using automatic mode to see if the control moves it properly. If the actuator moves in the opposite direction than it is supposed to, switch the positive and negative wires on the control.

**Phason Inc.**

2 Terracon Place

Winnipeg, Manitoba, Canada

R2J 4G7

Phone: 204-233-1400

Fax: 204-233-3252

E-mail: support@phason.ca

Web site: www.phason.ca